INSTRUCTION MANUAL

1. DESCRIPTION OF THE 4 BUTTONS



Reset (R) Exit the game to reselect your favorite character.
Select (S) Select the options.
Choose from the options.
Cancel (C) Exit the options or cancel the operation.

2. STARTING THE GAME

1. Remove the insulating film from the battery compartment.
2. Press the select key, and the screen will display 10 characters in order:

Press the decide key to select the character, set the time, and confirm the name EDUARDO. Then, little EDUARDO will be born.

3. MENU

PROFILE	EDUARDO's age. Exercise and education will help him grow.	Let's go EDUARDO Name
	EDUARDO's strength. Food will increase his strength.	CRISPY EDUARDO's crunch level. Making EDUARDO happy will improve his crunch level
	Eduardo's money. Playing games will earn you dollars. Lucky stars will also bring dollars.	Eduardo's weight. Eduardo's weight increases with his age.

FOOD	KFC Bucket	Burger	Fries	Drink	Ice Cream
BATHROOM	This icon appearing on the screen indicates that Eduardo needs to go to the bathroom. Take him to the bathroom.				
EDUCATION	Going to school will help Eduardo grow				

INSTRUCTION MANUAL

GAMES	Train EDWARD to catch the UFO flying overhead.	Fly with EDWARD, but... Watch out for the fork!
	Buy with $500 or, once you have them, you can see them in the treasure chest.	
REST	 "on" means activity time; "off" means rest time.	
EDUCATION	Going to school will help EDWARD grow.	
DOCTOR	This icon means EDWARD is sick.	Curing him in time will make him happy.
EMAIL	The more lucky stars, the better the luck.	The flashing icon indicates there is a message. The message can be good or bad. Gift or trap? You'll see.
INVENTORY	Guess the password. There is a secret gift if you enter the correct password.	See the gifts purchased last time in the treasure chest.
CALL	Eduardo will call you when he is sick, hungry, or needs to use the bathroom. Take care of him	